

NTG Motor Services Limited

282 - 284 Bramford Road Ipswich Suffolk IP1 4AY

Tel: ++44 (0)1473 - 406031 & 406032

Fax: ++44 (0)1473 - 743133 Email: sales@mgbits.com

www.mgbits.com www.bmcfarina.com

Directors: M.Green P.Banyard Company Reg.No. 1262476 V.A.T.Reg. No. 289 5422 17

To convert your cylinder head:

- I. Strip old cylinder head, check for cracks and then clean in caustic soda.
- II. After washing off the caustic solution in a hot wash tank, dry the head and grit blasted to remove any remaining carbon and to clean the waterways.
- III. Fit the Manganese silicon bronze valve guides and reame to size. (Bronze removes heat two and a half times faster than original cast iron valve guides.
- IV. Fit the Lead free exhaust seats inserts.
- V. Cut the valve seats using three angles, (30, 45 & 60 degree). This aids the flow and increases B.H.P. by approx 7% with premium lead-free fuel.
- VI. Blend the throat valves to remove any sharp edges caused by fitting the inserts and cutting the seats.
- VII. Skim Head if required.
- VIII. After de-burring, hot wash the head, dry, assemble and paint.

This procedure is best left to a qualified engineer/machinist and these instructions are offered as a guideline only!

